



**INSTRUCTIONS MANUAL**



## IMPORTANT

The controller delivered with this manual may be modified for specific needs.

In this case, please give us the controller serial number written on our shipping note or the approximate controller delivery date when you will place an order for a new similar controller or for spare parts.

In this way, you will be sure to get the required controller and/or spare parts.

## WARNING



This information has to be kept in a location known to all users.



Each operator has to read carefully this instructions manual before installing, using, and mending the product.

Be sure that the operator has understood usage recommendations and the meaning of signs put on the product.

Most accidents could be avoided respecting this Instructions Manual. As a matter of fact, they were created according to European laws and norms applied to the product.

In each case, please respect and follow national safety norms. Do not take off nor damage the stickers or notifications put on the product and above all the details imposed by the law.

## SUMMARY


|                                                                 |           |
|-----------------------------------------------------------------|-----------|
| <b>1. SPECIFICATIONS</b>                                        | <b>3</b>  |
| <b>2. HARDWARE</b>                                              | <b>4</b>  |
| 2.1 Dimensions and mounting interface                           | 4         |
| 2.2 Interface ports                                             | 5         |
| <b>3. GETTING STARTED</b>                                       | <b>6</b>  |
| <b>4. MAIN MENU</b>                                             | <b>6</b>  |
| <b>5. JOB MANAGER</b>                                           | <b>7</b>  |
| <b>6. NEW JOB CREATION</b>                                      | <b>8</b>  |
| 6.1 Fastening step creation                                     | 9         |
| 6.1.1 Manual programming of fastening step:                     | 10        |
| 6.1.2 Automatic programming of fastening step:                  | 11        |
| 6.1.3 Smart tolerance detection feature:                        | 11        |
| 6.2 Logical Input step creation                                 | 12        |
| 6.3 Logical Output step creation                                | 12        |
| 6.4 Delay step creation                                         | 12        |
| 6.5 Message step creation                                       | 13        |
| 6.6 Job example                                                 | 14        |
| <b>7. SETTINGS</b>                                              | <b>15</b> |
| 7.1 Operating                                                   | 15        |
| 7.2 Encoders                                                    | 17        |
| 7.3 Inputs                                                      | 18        |
| 7.4 Outputs                                                     | 19        |
| 7.5 Network                                                     | 20        |
| 7.6 Other                                                       | 20        |
| <b>8. OPERATING MODE</b>                                        | <b>21</b> |
| <b>9. ELECTRICAL WIRING</b>                                     | <b>22</b> |
| 9.1 Encoder's port wiring scheme                                | 22        |
| 9.2 RS232 port wiring scheme                                    | 22        |
| 9.3 Inputs wiring scheme                                        | 23        |
| 9.4 Outputs wiring scheme                                       | 24        |
| 9.5 Connection of DOGA low voltage tools GX/GY/DO/GA            | 25        |
| 9.6 Connection of DOGA Hybrid HDC and Current control SDC tools | 26        |
| 9.7 Connection of Stanley Alpha and Kappa tools                 | 28        |
| 9.8 Connection of Kolver EDU Series tools                       | 29        |
| 9.9 Two tools wiring example                                    | 30        |
| 9.10 Automation equipment wiring example                        | 31        |
| 9.11 I/O port adaptor (DB44 → DB25 + DB9) wiring scheme         | 32        |
| <b>10. Troubleshooting</b>                                      | <b>33</b> |

## 1. SPECIFICATIONS

| No                         | Specification                                                                                          |
|----------------------------|--------------------------------------------------------------------------------------------------------|
| 1. Input power             | DC24V, 1A<br>AC 100-240V / DC 24V adaptor is provided                                                  |
| 2. Dimensions              | 202(W) x 128(H) x 38(D) mm                                                                             |
| 3. Weight                  | 0.55 kg                                                                                                |
| 4. Screen                  | 7" LCD Touch screen, 800 x 480 px                                                                      |
| 5. Graphical interface     | Visualization of assembly process with graphical instructions                                          |
| 6. Inputs and Outputs 24V  | 12 inputs and 12 outputs with assignable functions<br>Logical I/O's for workstation automation         |
| 7. Analog encoders         | 4 channels, 0...5V                                                                                     |
| 8. Memory card             | Removable SD card, 8Gb                                                                                 |
| 9. Total jobs memory       | 999 jobs with open structure                                                                           |
| 10. Total positions memory | 999 jobs x 255 steps x 99 positions per fastening step<br>max 999 positions in one job (counter limit) |
| 11. Programming            | Automatic and manual programming of a Fastening step                                                   |
| 12. Positioning accuracy   | 0.09° for angular encoders<br><0.5 mm for linear encoders                                              |
| 13. Positioning tolerance  | Adjustable for each position and for each axis.<br>Smart tolerance detection feature.                  |
| 14. Compatible tools       | All tool with signals – electric or pneumatic.<br>Min required signals: «Fastening OK», «Tool Lock»    |
| 15. Communication          | RS232 for bar code scanner and firmware upgrade<br>Ethernet (not enabled in firmware v.0.2.8)          |

## 2. HARDWARE

### 2.1 Dimensions and mounting interface



Mounting plate with 4 x M3 screws is delivered with the controller as a standard accessory.

Weight of the controller: 0.55 kg


## 2.2 Interface ports



**NOTE:** ports shown in grey are not used in firmware v.0.2.8

### I/O port adaptor

This adaptor is used to split I/O signals for tool interface and other automation equipment (see Electric wiring chapter for the wiring scheme).



### Encoders port adaptor

(supplied only for controllers with serial numbers starting with SC\*\*\*\*\*)

Encoders port adaptor is used to connect standard DOGA positioning arms to DPC Touch.

**ATTENTION:** Do not connect positioning arm directly to DPC Touch (serial numbers starting with SC\*\*\*\*\*)! This may damage encoders!



### 3. GETTING STARTED

1. Connect power supply to the controller to turn it on. Normal booting time is about 2 sec. If controller is not booted, the last booting step indicates the problem (e.g. *Init SD Card...* - missing or damaged SD card).
2. After first booting, calibration screen may appear. Follow instructions on the screen -press and hold the center of the cross for 1 sec for each position of the cross.  
**ATTENTION:** if calibration is not correctly performed, the touch screen may become unresponsive. In this case turn off the controller, take out the SD card, access the SD card from your computer and delete the following file: **SD:\system\setting\Setting\_posi.dat**
3. Controller is started automatically in operating mode. If default job is selected it will start automatically.
4. Tap on the HOME button in order to access to the main menu screen. While not logged in, JOB MANAGER and SETTINGS are not accessible.
5. To log into the system tap on the LOGIN button. **Default factory password is "0".**

### 4. MAIN MENU



The main screen provides access to the main menu with four buttons:

- **Job manager**  
Provides access to the list of saved jobs and allows creation/modification jobs. This button is locked while user is logged out.
- **Operation mode**  
Provides access to the operating screen.
- **Settings**  
Provides access to the controller settings. This button is locked while the user is logged out.
- **Login/Logout**  
Allows logging into the system by entering the password to access *Job manager* and *Settings*.

**NOTE:** default factory password is "0". If the password is lost, turn off the controller, take out the SD card, access the SD card from PC and delete the following file: *SD:\system\setting\Setting\_posi.dat* After rebooting, the controller will be reset to default factory settings.

## 5. JOB MANAGER

Job manager interface provides access to the list of saved jobs. It also allows to *Edit* or to *Delete* saved jobs as well as to create new ones by pressing *New* button or by *Copying* an existing job. *Load* button is used to load selected job into operating mode.

**NOTE:** a job can't be loaded if it doesn't contain any steps.

 **Job manager**


| No | Job name                                            | Steps | Screws |
|----|-----------------------------------------------------|-------|--------|
| 1  | Chair_10:48                                         | 0     | 0      |
| 2  | Chair_10:49                                         | 1     | 1      |
| 3  | The_longest_name_01234567898765                     | 2     | 2      |
| 4  | Chair_11:49                                         | 3     | 3      |
| 5  | Chair_10:48                                         | 4     | 4      |
| 6  | Chair_10:48                                         | 5     | 5      |
| 7  | The_longest_name_01234567898765                     | 6     | 6      |
| 8  | Chair_10:48                                         | 6     | 6      |
| 9  | Chair_10:48                                         | 6     | 6      |
| 10 | The_longest_job_name_012345678901234567890123456789 | 6     | 6      |
| 11 | Chair_10:48                                         | 1     | 1      |
| 12 | The_longest_job_name_012345678901234567890123456789 | 1     | 1      |

⬆ ⬇
New Copy Load Edit Delete

Each job has its sequential number (No). In order to change job number tap one more time on the selected job and then change its position in the list by using *Up* and *Down* buttons.

For information purposes number of steps and screws in a job is displayed in corresponding line in the list.

*Home* button provides access to the main menu screen.

Maximum number of jobs is 999.

**NOTE:** while not logged in, the only active buttons are *Load* and *Home*, other buttons are locked.

## 6. NEW JOB CREATION

While in Job Manager screen, press NEW button. New job will be created and placed in the end of the list. New job creation screen will be displayed automatically.

A job is represented by a sequence of steps. These steps can be organized in any order which corresponds to the desired production sequence. There are 5 types of steps and each one of them can be used multiple times if necessary.

- **Fastening:** this step contains fastening positions including information associated with these positions (positioning tolerance, tightening program, tightening time, etc.)
- **Logical In:** this step is used to verify an input signal in order to pass to the next step (e.g. signals from proximity sensors, buttons, etc.).
- **Logical Out:** this step is used to send an output signal(s) to manage automation equipment on work station (e.g. activation of pneumatic valves, lights, etc.).
- **Delay:** this step allows to maintain the current state of I/O's for specified time (e.g. a delay required between receiving an input signal and sending an output signal).
- **Message:** this step is used to display a graphical or text message on the operating screen during working cycle.

A job may contain up to 255 steps. The maximum number of positions in a single fastening step is 99.

In order to change sequence of steps in a job, tap one more time on the selected step and then change its position in the list by using *Up* and *Down* buttons.

Created steps can be modified by using EDIT button or deleted by using DELETE button. COPY button creates a copy of the selected step and inserts it in the end of the list.

Press SAVE button to save the job or CANCEL button to quit programming without saving changes.

## 6.1 Fastening step creation

**NOTE:** it is useful to define encoder's reference point before creating a fastening step. See encoder's settings for more information.

While in Job creation screen, tap on FASTENING step button. The Fastening step creation screen will appear.


**Current** field displays the number of position being programmed.

**Saved** field displays the total number of saved position in the fastening step being programmed.

**Current channels** fields display current values from analog encoders. Only active channels are shown.

**Saved channels** fields display saved values from analog encoders. Current values are saved when Apply button is pressed or when Fastening OK signal is received.

**Tolerance** fields display tolerance values for analogue encoders to be applied for each encoder for the current position. Tolerance values can be automatically detected by using Smart Tolerance detection feature (please refer to corresponding chapter for more details).



**NOTE:** real shapes of tolerance areas are not circular; they depend on the geometry of the positioning arm being used. To avoid overlapping of tolerance areas of different screws, keep tolerance values as low as possible.

**Time control** fields display measured Tightening time and calculated Min and Max limits. Min and Max values are calculated according to percentages defined in operating settings.

**Tightening job** is a preset number to be selected for the current tightening position via 24V outputs (direct or binary logic) if supported by the tool.

**Retightening job** is similar to the Tightening job but it is used only for rework operation and it is automatically selected after NG tightening (if retightening is enabled in operating settings).

**Pick up positions** 1 and 2 can be selected to allow to start the tool in a specific position or area (outside position OK zone) in order to pick up a screw. Fastening OK signals and Motor run signals are not effective on pick-up position.

**Driver** 1 and 2 selection is only applied to DOGA tools (GX, GY, DO, GA) connected through RJ45 port. This selection allows enabling and disabling tools for each individual position.

**Reset** button is used to reset current position data to default values. To delete a position press Reset button one more time after resetting the position data to defaults.

**NOTE:** there is no need to use APPLY button after modification of any of the above values. APPLY button is only used to save current values from encoders for the current position.

A Fastening step can be programmed manually or automatically.

#### 6.1.1 Manual programming of fastening step:

0. *Optional: Use Smart tolerance detection feature (refer to Smart tolerance detection below)*
1. Position the arm on the first screw.  
Encoders monitoring fields are displaying the current position of the arm.
2. Press APPLY button to save current position of the arm. Saved values from encoders will be displayed in corresponding fields. If not satisfied with the result press APPLY button again to rewrite saved values from encoders.
3. Default tolerance values for the approaching Area and for the OK zone are applied. To change default values refer to encoders' settings. Tolerance values can be adjusted manually for each individual position or by using Smart tolerance detection feature.
4. If necessary, define Tightening and Retightening programs to be used for the current position, feeding point (see Pick Up positions in encoders' settings) and the screwdriver to be used for this tightening position (used only for DOGA GX/GY/DO/GA tools).
5. If necessary, enter Min and Max tightening time limits in corresponding fields. Tightening time control is not used if limits are equal to 0.
6. Press NEXT button to pass to the next position.
7. Repeat 1-6 for each position.
8. Activate Non-sequential mode if there is no need to keep strict tightening sequence.  
**NOTE:** in non-sequential mode, retightenings can't be managed.
9. Press SAVE button to save the step or CANCEL button to quit programming without saving changes.

### 6.1.2 Automatic programming of fastening step:

For automatic programming, make sure that the tool is connected to the controller and signals are correctly assigned. In order to register tightening time, Motor run and Fastening OK signals have to be connected.

0. *Optional: Use Smart tolerance detection feature (refer to Smart tolerance detection below)*
1. Position the arm on the first screw.  
Monitoring fields are displaying the current position of the arm.
2. Default tolerance values for the approaching Area and for the OK zone will be applied. To change default values refer to encoders settings. Tolerance values can be adjusted manually for each individual position or by using Smart tolerance detection feature.
3. If necessary, define Tightening and Retightening programs to be used for the current position, feeding point (see Pick Up position in encoders' settings) and the tool being used.
4. Perform a tightening operation as it has to be performed during production.
5. Tightening time will be registered automatically. Min and Max tightening time limits are calculated automatically by using default values in operating settings. Tightening time control is not used if limits are equal to 0.
6. Repeat 1-5 for each position.
7. Activate Non-sequential mode if there is no need to keep strict tightening sequence.  
NOTE: in non-sequential mode, retightenings can't be managed.
8. Press SAVE button to save the step or CANCEL button to quit programming without saving changes.

### 6.1.3 Smart tolerance detection feature:

This feature allows automatic detection of OK zone tolerance for each position. Motor Run signal has to be connected in order to use this feature.

1. Press START button to begin smart tolerance detection.
2. Start the tool and move it around the screw to define OK zone (the zone where operator is allowed to run the tool).
3. Stop the tool and press STOP button on the screen.  
Or perform a tightening operation as it has to be performed during production.  
In this case tightening time will be saved automatically together with detected tolerance values and current position coordinates. Next position teaching will start automatically.
4. Continue with Manual or Automatic programming.

## 6.2 Logical Input step creation

While in Job modification screen, tap on LOGICAL IN button. The Logical In step creation screen will appear.

Select an available input from the list of Inputs. If an Input was assigned for a specific function in Input settings it is not available to be used as a logical signal.

Select the type of the signal. There are four types of input signals:

- **Active High:** for this type of signal it is necessary to detect a transition from 0 to 1.
- **Active Low:** for this type of signal it is necessary to detect a transition from 1 to 0.
- **Status High:** for this type of signal it is enough to detect if the signal is equal to 1.
- **Status Low:** for this type of signal it is enough to detect if the signal is equal to 0.

Logical input step is completed if the corresponding input signal matches the condition of the selected signal type.

If two or more signals are selected, then AND condition will be applied for selected signals to complete the step.

Press SAVE button to save the step or CANCEL button to quit programming without saving changes.

## 6.3 Logical Output step creation

While in Job modification screen, tap on LOGICAL OUT button. The Logical Out step creation screen will appear.

Select an available output and its type from the list of Outputs. If an Output was assigned for a specific function in Output settings it is not available to be used as a logical signal.

There are two types of output signals:

- **Continuous ON:** the signal is continuous until it is deactivated in the next Logical Out step. To deactivate the signal, create a new Logical Out step and deselect the corresponding signal.
- **Impulse:** the signal is an impulse with defined duration. Duration of the signal is defined in ms.

Multiple output signals can be used in the same Logical Out step.

Press SAVE button to save the step or CANCEL button to quit programming without saving changes.

## 6.4 Delay step creation

While in Job modification screen, tap on DELAY button. The message step creation screen will appear.

The controller will stay on hold for the defined time. Delay step can be used to manage timing between Logical In and Logical Out steps or between messages.

Press SAVE button to save the step or CANCEL button to quit programming without saving changes.

## 6.5 Message step creation

While in Job modification screen, tap on MESSAGE button. The message step creation screen will appear.

Enter the text to be displayed and activate the corresponding switch.

Select an image to be displayed from the list of available images and activate the corresponding switch. To hide the displayed message it is necessary to create a new Message step without text and/or image.

Images are stored on SD card in the following directory: **SD: \user\images\messages**


For the best result, use pictures with the following format: **800 x 480 px, 16 bit, RGB565 BMP**

NOTE: standard 24 bit BMP images can be used, but processing time will be longer. Use provided converter utility to convert 24 bit images into 16 bit for better productivity.

Press SAVE button to save the step or CANCEL button to quit programming without saving changes.

### Creating 16 bit bitmap images with Image Converter utility

1. Open Image converter utility
2. Select the directory where converted images are to be saved.  
NOTE: Image Converter will create a new folder "16bit" where converted files will be saved.
3. Add image files to be converted by using *Add* button. If necessary remove files by using *Remove* button.  
NOTE: images have to be in **.jpeg** or **.bmp** formats cropped to the size of **800x480 px**
4. Press *Convert* button to convert images into 16 bit bitmap format. Converted images will be saved in the specified directory in "16bit" folder.
5. Close Image Converter utility.



## 6.6 Job example

A simple job may contain only a Fastening step, which will assure screws counting and tool position control functions.

Example below illustrates a job for management of an automated station with multiple sensors and actuators.

This job uses 5 logical inputs, 4 logical outputs, 7 messages (text and/or image) and 2 fastening steps.

| No | Step type   | Step functions                                                                                                                                                                                                                            |
|----|-------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 1  | Message     | Text or Image message appears on the screen to indicate what workpiece has to be assembled. Image stays on the screen until replaced by next message or until screen is touched.                                                          |
| 2  | Logical In  | Three input signals (active high) are expected from proximity switch to detect presence of the workpiece on the table and from two buttons which operator has to press simultaneously in order to keep his hands off the clamping device. |
| 3  | Message     | Text or Image message is shown on the screen to warn the operator about closing clamping device.                                                                                                                                          |
| 4  | Delay       | A short delay is used before activation of the clamping device.                                                                                                                                                                           |
| 5  | Logical Out | Two output signals (continuous) are sent to activate the clamping device to lock the workpiece on the table and to turn on assembly status light.                                                                                         |
| 6  | Message     | Text or Image message is shown on the screen to indicate parts to be picked                                                                                                                                                               |
| 7  | Logical Out | One output signal (continuous) is sent to turn on pick to light indicator 1                                                                                                                                                               |
| 8  | Logical In  | One input signal (active high) is expected for picking verification by sensor 1                                                                                                                                                           |
| 9  | Logical Out | Pick to light indicator 1 is turned off once picking is performed                                                                                                                                                                         |
| 10 | Message     | Text or Image message is shown on the screen to indicate first fastening operations to be performed.                                                                                                                                      |
| 11 | Fastening   | First fastening operations are performed, screws are counted and tool position is assured.                                                                                                                                                |
| 12 | Message     | Text or Image message is shown on the screen to indicate parts to be picked                                                                                                                                                               |
| 13 | Logical Out | One output signal (continuous) is sent to turn on pick to light indicator 2                                                                                                                                                               |
| 14 | Logical In  | One input signal (active high) is expected for picking verification by sensor 2                                                                                                                                                           |
| 15 | Logical Out | Pick to light indicator 2 is turned off once picking is performed                                                                                                                                                                         |
| 16 | Message     | Another message is shown on the screen to indicate second fastening operations to be performed.                                                                                                                                           |
| 17 | Fastening   | Second fastening operations are performed, screws are counted and tool position is assured.                                                                                                                                               |
| 18 | Logical Out | Two output signals are disabled to open the clamping device and to turn off assembly status light.                                                                                                                                        |
| 19 | Message     | Job completion message                                                                                                                                                                                                                    |
| 20 | Delay       | Delay before the job is restarted                                                                                                                                                                                                         |

## 7. SETTINGS

### 7.1 Operating

#### Screen 1 of 4: Management of interface

| Parameter                          | Description                                                                                                                                                                                                                                                                                                                                                                    | Range   | Default value |
|------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------|---------------|
| Tool selection                     | Select one of the following option:<br>- <b>HDC/SDC</b> : DOGA Hybrid or Current control tools (HDC30i, HDC35i, HDC40i, SDC24, SDC40)<br>- <b>DC tools</b> : all electric digital control tools equipped with 24V I/O signals<br>- <b>GX, GY, DO, GA</b> : DOGA low voltage tools (XS-40D, XS-38D, XT-30D, XS-35D, XT-35D)<br>- <b>Other</b> : special applications on request | -       | DC tools      |
| Screws counting up/down            | This parameter manages counting display. Turn it ON to count up (1,2,3,...) or OFF to count down (...3,2,1)                                                                                                                                                                                                                                                                    | ON/OFF  | ON            |
| Screws counting for step/job       | This parameter manages counting display. Turn it ON to display counting separately for each step or OFF to display counting for the whole job.                                                                                                                                                                                                                                 | ON/OFF  | ON            |
| Torque selection by binary outputs | Selection of tightening presets for each position is done via Torque selection outputs. These outputs can function in binary logic or in direct logic (one output per preset).                                                                                                                                                                                                 | ON/OFF  | ON            |
| Job selection by binary inputs     | Selection of Jobs of DPC Touch can be done via Job selection inputs. These inputs can function in binary logic or in direct logic (one input per job).                                                                                                                                                                                                                         | ON/OFF  | ON            |
| Default job number                 | Default job is a job which is automatically started after booting of DPC Touch. If default job number is set to 0, DPC Touch will not boot any jobs.<br>NOTE: job selection via inputs has higher priority                                                                                                                                                                     | 0 - 999 | 1             |

#### Screen 2 of 4: Management of buttons in operating mode

|                                       |                                                                                                                                                                                          |        |    |
|---------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------|----|
| Skip button access without password   | Enables access to Skip button without entering password. If turned OFF the password will be asked when Skip button is pressed.                                                           | ON/OFF | ON |
| Back button access without password   | Enables access to Back button without entering password. If turned OFF the password will be asked when Back button is pressed.                                                           | ON/OFF | ON |
| Reset button access without password  | Enables access to Reset button without entering password. If turned OFF the password will be asked when Reset button is pressed.                                                         | ON/OFF | ON |
| Display job reset button              | Job reset button can be displayed or hidden by using this parameter.<br>NOTE: if turned OFF and automatic reset is used, then the current step will be reset instead of the current job. | ON/OFF | ON |
| Job selection access without password | Enables access to Jobs selection without entering password. If turned OFF the password will be asked when Job selection button is pressed.                                               | ON/OFF | ON |

**Screen 3 of 4: Management of fastening time**

|                                      |                                                                                                                                                                                                                                                                                                                                                                                                                                                                          |          |     |
|--------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------|-----|
| Min fastening time limit, %          | Lower limit of fastening time control in percentage of actual fastening time detected during programming.<br>NOTE: changes will be applied only to new jobs, existing jobs won't be affected.                                                                                                                                                                                                                                                                            | 0 - 100  | 25  |
| Max fastening time limit, %          | Upper limit of fastening time control in percentage of actual fastening time detected during programming.<br>NOTE: changes will be applied only to new jobs, existing jobs won't be affected.                                                                                                                                                                                                                                                                            | 0 - 100  | 25  |
| Start trigger release time limit, ms | Fastening time threshold after which trigger release will be considered as NG tightening. Error message "Trigger released before Torque Up" will appear.                                                                                                                                                                                                                                                                                                                 | 0 - 9999 | 0   |
| Temporary position loss time, ms     | If fastening is started (Motor Run signal is received), then it is allowed to exit position OK zone (green) into approaching area (orange) for the specified time without locking the tool. If this time limit is passed the tool will be instantly locked. If position NOK zone (red) is entered the tool will be instantly locked.<br>NOTE: this parameter is used to avoid interruptions of fastening process when position is lost for short time due to vibrations. | 0 - 3000 | 50  |
| Judging time, ms                     | Judging time is used if Fastening OK signal is delayed after the fall of Motor run signal.                                                                                                                                                                                                                                                                                                                                                                               | 0 - 500  | 100 |

**Screen 4 of 4: Management of NG tightenings**

|                                         |                                                                                                                                                                                                                                                                            |          |      |
|-----------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------|------|
| Number of retightenings on a position   | Maximum number of attempts to rework a NG fastening. If the maximum number of attempts is reached the current position can be skipped or Job/Step can be reset according to parameters selected.<br>NOTE: this parameter is not effective in non-sequential assembly mode. | 0 - 10   | 1    |
| Skip NG tightening                      | Allows to skip automatically a NG tightening if rework is not allowed or if rework wasn't successful.                                                                                                                                                                      | ON/OFF   | OFF  |
| Fastening NG signal if position skipped | If turned ON, Fastening NG signal will be provided when a position is skipped automatically, by Skip button on the operating screen or by external input. If turned OFF, Fastening OK signal will be provided.                                                             | ON/OFF   | ON   |
| Auto reset delay, ms                    | Alarm can be reset automatically after the specified delay. If delay is equal to 0 than reset has to be done manually or by external input.                                                                                                                                | 0 - 9999 | 3000 |

## 7.2 Encoders

| Encoders                                                                                   |                              |                            |        |
|--------------------------------------------------------------------------------------------|------------------------------|----------------------------|--------|
| Encoders settings will be applied only to new jobs.<br>Existing jobs will not be affected. |                              |                            |        |
| Connected channels                                                                         | Position area tolerance, pts | Position OK tolerance, pts |        |
| <input checked="" type="checkbox"/> Channel 1                                              | + <input type="text"/> -     | + <input type="text"/> -   |        |
| <input checked="" type="checkbox"/> Channel 2                                              | + <input type="text"/> -     | + <input type="text"/> -   |        |
| <input checked="" type="checkbox"/> Channel 3                                              | + <input type="text"/> -     | + <input type="text"/> -   |        |
| <input checked="" type="checkbox"/> Channel 4                                              | + <input type="text"/> -     | + <input type="text"/> -   |        |
| ◀ Previous                                                                                 |                              | Screen 1 of 2              | Next ▶ |

| Encoders                                     |                                              |                                              |                                              |
|----------------------------------------------|----------------------------------------------|----------------------------------------------|----------------------------------------------|
| Pick up position 1                           |                                              | Pick up position 2                           |                                              |
| <input checked="" type="checkbox"/> Corner 1 | <input checked="" type="checkbox"/> Corner 2 | <input checked="" type="checkbox"/> Corner 1 | <input checked="" type="checkbox"/> Corner 2 |
| Ch1 <input type="text"/>                     | <input type="text"/>                         | <input type="text"/>                         | <input type="text"/>                         |
| Ch2 <input type="text"/>                     | <input type="text"/>                         | <input type="text"/>                         | <input type="text"/>                         |
| Reset                                        | Reset                                        | Reset                                        | Reset                                        |
| Pick                                         | Pick                                         | Pick                                         | Pick                                         |
| Set zero position of encoders                |                                              | Pick                                         | Reset                                        |
| ◀ Previous                                   |                                              | Screen 2 of 2                                | Next ▶                                       |

### Encoder's activation and tolerance settings (screen 1 of 2)

Activate or deactivate corresponding encoders by selecting check boxes accordingly.

Enter default tolerance values for the approaching Area and for OK zone where tool is enabled. Default tolerance values are applied automatically during Fastening step creation. It is possible to modify tolerances manually for each individual position during creation of a fastening step.

If default tolerances are changed they will be applied only to new jobs, existing jobs will not be affected.

See more information about approaching Area and OK zone tolerances in Fastening step creation chapter.

### Pick up position 1 and 2 (screen 2 of 2)

It is possible to define two screw feeding positions or areas. The tool can be enabled on the corresponding feeding position for easier screw picking.

Pick up position can be defined as a single point (Corner 1) or as an area between Corner 1 and Corner 2 (see below).



**NOTE:** the real shape of pick-up area is not rectangular and depends on the geometry of the arm.

To register location of a corresponding corner, position the arm and press *Pick* button.

### Setting zero point of encoders (screen 2 of 2)

Encoders' reference point can be defined by using this function. Definition of the reference point is useful when encoders have to be replaced after failure or when repeatability of position of the workpiece can't be assured.

The reference point can be defined by using *Pick* button or reset by using *Reset* button. The reference point can also be defined by using external input signal in Operating mode.

### 7.3 Inputs

Activate necessary inputs by selecting corresponding check boxes. Select required input function from the list.

Non-assigned inputs can be used for Logical In steps.

Impulse signals duration must be between 100 and 500 ms.

Each input function can be assigned only once.

| Input name     | Function description                                                                                                                                                                                                                                               | Signal type           |
|----------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------------|
| Job select 1-8 | Inputs to select jobs on DPC Touch in binary or in direct logic (see the table below). Logic is selected in operating settings.                                                                                                                                    | Continuous            |
| Skip           | Signal is used to skip the current step or position.                                                                                                                                                                                                               | Impulse               |
| Back           | Signal is used to get back to previous position. It's not possible to get back to previous step.                                                                                                                                                                   | Impulse               |
| Reset          | DPC Touch alarm reset. If maximum number of retightenings is reached it's not possible to reset the alarm. Step or Job has to be reset.                                                                                                                            | Impulse               |
| Reset Step     | Signal is used to reset current fastening step.                                                                                                                                                                                                                    | Impulse               |
| Reset Job      | Signal is used to reset current job.                                                                                                                                                                                                                               | Impulse               |
| Next Job       | Signal is used to select next job in the job manager list.                                                                                                                                                                                                         | Impulse               |
| Previous Job   | Signal is used to select previous job in the job manager list.                                                                                                                                                                                                     | Impulse               |
| Tool Alarm     | Fastening NG (alarm) signal from the tool to indicate that fastening operation wasn't successful.                                                                                                                                                                  | Continuous or Impulse |
| Set Origin     | Signal is used to set zero of encoders in operating mode.                                                                                                                                                                                                          | Impulse               |
| D_Reverse      | Signal from tool to indicate that the tool is in reverse rotation mode. DPC Touch will lock the tool if the signal is received on the first tightening. After NG tightening DPC Touch will not lock the tool if this signal is received to allow rework operation. | Continuous            |
| D_Motor_Run    | Signal from tool to indicate that the tool is running. Signal is used to control fastening time and to assure functioning of Smart tolerance teaching feature and Temporary position loss feature.                                                                 | Continuous            |
| D_Fastening_OK | Signal from tool after successful fastening operation. Once the signal is received, current position is declared as finished.                                                                                                                                      | Impulse               |

The table below shows the relation between Job select signals and Job number in binary logic.

| Job number | Job select 1 | Job select 2 | Job select 3 | ... | Job select 8 |
|------------|--------------|--------------|--------------|-----|--------------|
| 0          | 0            | 0            | 0            | 0   | 0            |
| 1          | 1            | 0            | 0            | 0   | 0            |
| 2          | 0            | 1            | 0            | 0   | 0            |
| 3          | 1            | 1            | 0            | 0   | 0            |
| 4          | 0            | 0            | 1            | 0   | 0            |
| ...        |              |              |              |     |              |
| 255        | 1            | 1            | 1            | 1   | 1            |

*NOTE: See Output's settings for direct logic example.*

## 7.4 Outputs

Activate desired outputs by selecting corresponding check boxes. Select required output type from the list.

Non-assigned outputs can be used for Logical Out steps.

Duration of impulse signals is 100 ms.

Each output function can be assigned to multiple outputs.

| Output name       | Function description                                                                                                                      | Signal type |
|-------------------|-------------------------------------------------------------------------------------------------------------------------------------------|-------------|
| Fastening OK      | Signal is provided after successful fastening operation.                                                                                  | Impulse     |
| Fastening NG      | Signal is provided after a fastening operation completed with errors.                                                                     | Impulse     |
| Step OK           | Signal is provided after successful completion of a step.                                                                                 | Impulse     |
| Step NG           | Signal is provided after if a step was interrupted or completed with missing screws.                                                      | Impulse     |
| Tool Enable       | Signal is provided to enable the tool (when position is OK)                                                                               | Continuous  |
| Tool Disable      | Signal is provided to lock the tool (when position is NOK or during alarm mode)                                                           | Continuous  |
| D_RUN             | Signal is provided when the tool is running (D_Motor_Run input has to be connected)                                                       | Continuous  |
| D_TORQUE          | Signal is provided when Fastening OK signal is received from the tool (D_Fastening_OK input has to be connected)                          | Impulse     |
| D_RESET           | Signal is provided when reset was made (manually, automatically or via I/O)                                                               | Impulse     |
| Torque Select 1-8 | Signals to select fastening presets on the tool in binary or direct logic (see the table below). Logic is selected in operating settings. | Continuous  |
| Job OK            | Signal is provided after successful completion of a job.                                                                                  | Impulse     |
| Job NG            | Signal is provided after if a job was interrupted or completed with missing screws.                                                       | Impulse     |
| System Ready      | Signal is provided when the controller is in operating mode and ready for selection of jobs. Once a job is started the signal drops down. | Continuous  |
| Alarm             | Signal is provided when the controller is in Alarm mode                                                                                   | Continuous  |

The table below shows the relation between Torque select signals and Preset number in direct logic.

| Pset number | Torque select 1 | Torque select 2 | Torque select 3 | ... | Torque select 8 |
|-------------|-----------------|-----------------|-----------------|-----|-----------------|
| 0           | 1               | 0               | 0               | 0   | 0               |
| 1           | 0               | 1               | 0               | 0   | 0               |
| 2           | 0               | 0               | 1               | 0   | 0               |
| ...         |                 |                 |                 |     |                 |
| 8           | 0               | 0               | 0               | 0   | 1               |

*NOTE: See Input's settings for binary logic example.*

## 7.5 Network

Network communication is not enabled in firmware v.0.2.8

## 7.6 Other

### Real time monitoring of encoders and I/O's (screen 1 of 4)

This interface helps to verify if encoders function correctly. It also helps to check status of input signals and to force output signals to test wiring.

### Touch screen calibration (screen 2 of 4)

Press on *Start* button to enter into touch screen calibration mode. Press and hold indicated positions for 2 seconds in order to calibrate the screen.

**ATTENTION:** if calibration is not correctly performed, the touch screen may become unresponsive. In this case turn off the controller, take out the SD card, access the SD card from your computer and delete the following file: **SD:\system\setting\Setting\_posi.dat**

### Sounds (screen 2 of 4)

Adjust the volume by using the slide bar.

Select desired sounds for Position Ok, Alarm and Cycle complete signals. Activate sounds to be used.

### Date and time (screen 3 of 4)

Adjust current date and time. The controller is equipped with internal battery to keep this data.

### Language (screen 3 of 4)

Select language of the graphical interface. Available languages in firmware v.0.2.8:

English, French, German, Spanish

### Password (screen 4 of 4)

Enter the new password and press Set.

Default factory password is "0".

**NOTE:** If the password is lost, turn off the controller, take out the SD card, access the SD card from your computer and delete the following file: *SD:\system\setting\Setting\_posi.dat*

After rebooting, the controller will be reset to default factory settings.

### Controller reset to factory settings (screen 4 of 4)

Enter "77" to reset the controller to factory settings. Saved jobs will not be deleted.


### Firmware version (screen 4 of 4)

Current firmware version of the controller. Upgrade the firmware regularly to keep the controller up to date. Refer to the firmware upgrade manual for the upgrade procedure.

## 8. OPERATING MODE

Controller is started automatically in Operating mode after booting. Default job is loaded automatically (see operating settings). Operating mode is accessible through the main menu and through Job Manager by pressing Load button.

In Operating screen functions are managed in Operating settings.



In operating mode the following error messages can occur:


- **Fastening time is too long/short:** fastening time is out of min/max limits (see programming)
- **Trigger released before torque up:** tool was stopped before reaching torque (see settings)
- **Fastening NG (tool alarm):** fastening NG (alarm) input signal is received from the tool
- **System error:** operating system error (reboot the controller)
- **I/O error:** error of management of inputs and outputs (check logical and assigned I/O's)
- **Job complete NG:** job was interrupted or completed with missing screws

## 9. ELECTRICAL WIRING

### 9.1 Encoder's port wiring scheme


| Pin | Function        |
|-----|-----------------|
| 1   | 5V power supply |
| 2   | Channel (1)     |
| 3   | Channel (2)     |
| 4   | GND (Ch1, Ch3)  |
| 5   | GND (Ch2, Ch4)  |
| 6   | Channel (3)     |
| 7   | 24V (Ch1, Ch3)  |
| 8   | 24V (Ch2, Ch4)  |
| 9   | Channel (4)     |

| Only for serial numbers<br>SC***** |                 |
|------------------------------------|-----------------|
| 1                                  | 5V power supply |
| 2                                  | Channel (1)     |
| 3                                  | Channel (2)     |
| 4                                  | GND (Ch1, Ch3)  |
| 5                                  | GND (Ch2, Ch4)  |
| 6                                  | Channel (3)     |
| 7                                  | 24V (Ch1, Ch3)  |
| 8                                  | 24V (Ch2, Ch4)  |
| 9                                  | Channel (4)     |




### 9.2 RS232 port wiring scheme

| Pin | Function |         |
|-----|----------|---------|
|     | Port 1   | Port 2  |
| 1   |          | RX (2)  |
| 2   | RX (1)   |         |
| 3   | TX (1)   |         |
| 4   |          |         |
| 5   | GND (1)  |         |
| 6   |          | TX (2)  |
| 7   |          |         |
| 8   |          |         |
| 9   |          | GND (2) |




**NOTE:** for the firmware upgrade mode pins 7 and 8 have to be short connected (refer to the firmware upgrade manual).

### 9.3 Inputs wiring scheme






## 9.4 Outputs wiring scheme



**NOTE:** All outputs are optically isolated. Max current capacity is 100mA per output. Total of 500mA.


## 9.5 Connection of DOGA low voltage tools GX/GY/DO/GA

Two tools can be simultaneously connected to corresponding ports DR1 and DR2

| DPCTouch                                                                                                                                                                                                                                                                                 | DOGA GX/GY/DO/GA*                                                                                               |            |                 |   |                 |   |                    |      |     |   |                                                                                                                                                                                                                                                                                           |            |        |   |                  |   |                  |      |                   |   |     |
|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------|------------|-----------------|---|-----------------|---|--------------------|------|-----|---|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------|--------|---|------------------|---|------------------|------|-------------------|---|-----|
|                                                                                                                                                                                                         |                               |            |                 |   |                 |   |                    |      |     |   |                                                                                                                                                                                                                                                                                           |            |        |   |                  |   |                  |      |                   |   |     |
| <p><b>RJ45 I/O port 1 and 2</b></p>                                                                                                                                                                    | <p><b>RJ45 I/O port</b></p>  |            |                 |   |                 |   |                    |      |     |   |                                                                                                                                                                                                                                                                                           |            |        |   |                  |   |                  |      |                   |   |     |
| <table border="1"> <thead> <tr> <th>Signal</th><th>RJ45 pin №</th></tr> </thead> <tbody> <tr> <td>Torque Up input</td><td>2</td></tr> <tr> <td>Motor Run input</td><td>3</td></tr> <tr> <td>Driver Lock output</td><td>5, 6</td></tr> <tr> <td>24V</td><td>4</td></tr> </tbody> </table> | Signal                                                                                                          | RJ45 pin № | Torque Up input | 2 | Motor Run input | 3 | Driver Lock output | 5, 6 | 24V | 4 | <table border="1"> <thead> <tr> <th>RJ45 pin №</th><th>Signal</th></tr> </thead> <tbody> <tr> <td>2</td><td>Torque Up output</td></tr> <tr> <td>3</td><td>Motor Run output</td></tr> <tr> <td>5, 6</td><td>Driver Lock input</td></tr> <tr> <td>4</td><td>24V</td></tr> </tbody> </table> | RJ45 pin № | Signal | 2 | Torque Up output | 3 | Motor Run output | 5, 6 | Driver Lock input | 4 | 24V |
| Signal                                                                                                                                                                                                                                                                                   | RJ45 pin №                                                                                                      |            |                 |   |                 |   |                    |      |     |   |                                                                                                                                                                                                                                                                                           |            |        |   |                  |   |                  |      |                   |   |     |
| Torque Up input                                                                                                                                                                                                                                                                          | 2                                                                                                               |            |                 |   |                 |   |                    |      |     |   |                                                                                                                                                                                                                                                                                           |            |        |   |                  |   |                  |      |                   |   |     |
| Motor Run input                                                                                                                                                                                                                                                                          | 3                                                                                                               |            |                 |   |                 |   |                    |      |     |   |                                                                                                                                                                                                                                                                                           |            |        |   |                  |   |                  |      |                   |   |     |
| Driver Lock output                                                                                                                                                                                                                                                                       | 5, 6                                                                                                            |            |                 |   |                 |   |                    |      |     |   |                                                                                                                                                                                                                                                                                           |            |        |   |                  |   |                  |      |                   |   |     |
| 24V                                                                                                                                                                                                                                                                                      | 4                                                                                                               |            |                 |   |                 |   |                    |      |     |   |                                                                                                                                                                                                                                                                                           |            |        |   |                  |   |                  |      |                   |   |     |
| RJ45 pin №                                                                                                                                                                                                                                                                               | Signal                                                                                                          |            |                 |   |                 |   |                    |      |     |   |                                                                                                                                                                                                                                                                                           |            |        |   |                  |   |                  |      |                   |   |     |
| 2                                                                                                                                                                                                                                                                                        | Torque Up output                                                                                                |            |                 |   |                 |   |                    |      |     |   |                                                                                                                                                                                                                                                                                           |            |        |   |                  |   |                  |      |                   |   |     |
| 3                                                                                                                                                                                                                                                                                        | Motor Run output                                                                                                |            |                 |   |                 |   |                    |      |     |   |                                                                                                                                                                                                                                                                                           |            |        |   |                  |   |                  |      |                   |   |     |
| 5, 6                                                                                                                                                                                                                                                                                     | Driver Lock input                                                                                               |            |                 |   |                 |   |                    |      |     |   |                                                                                                                                                                                                                                                                                           |            |        |   |                  |   |                  |      |                   |   |     |
| 4                                                                                                                                                                                                                                                                                        | 24V                                                                                                             |            |                 |   |                 |   |                    |      |     |   |                                                                                                                                                                                                                                                                                           |            |        |   |                  |   |                  |      |                   |   |     |


\*Controllers XT-30D, XS-38D, XS-40D, XS-35D, XT-35D

**NOTE:** Select GX/GY/DO/GA tool interface in DPC Touch operating settings.  
The tool is locked by short connecting contacts 5 and 6.




**ATTENTION!** Use only straight RJ45-RJ45 cable (not crossed).

## 9.6 Connection of DOGA Hybrid HDC and Current control SDC tools

| DPCTouch                                                                                                                                           |                 |           | DOGA HDC/SDC series                                                                                                          |                 |
|----------------------------------------------------------------------------------------------------------------------------------------------------|-----------------|-----------|------------------------------------------------------------------------------------------------------------------------------|-----------------|
|                                                                   |                 |           |                                            |                 |
| <b>I/O adaptor</b><br>(DB44 male to DB9 female and DB25 female)  |                 |           | <b>DB25 I/O port</b><br>(potential free)  |                 |
| Input/Output                                                                                                                                       | Assigned signal | DB9 pin № | HDC/SDC pin №                                                                                                                | Signal          |
| Output 1                                                                                                                                           | Torque Select 1 | 1         | 1                                                                                                                            | Preset select 1 |
| Output 2                                                                                                                                           | Torque Select 2 | 2         | 2                                                                                                                            | Preset select 2 |
| Output 3                                                                                                                                           | Torque Select 3 | 3         | 3                                                                                                                            | Preset select 3 |
| Output 4                                                                                                                                           | Tool Disable    | 4         | 5                                                                                                                            | Driver Lock     |
| Input 8                                                                                                                                            | D_Motor_Run     | 5         | 16                                                                                                                           | Motor Run       |
| Input 9                                                                                                                                            | Tool Alarm      | 6         | 18                                                                                                                           | Alarm           |
| Input 10                                                                                                                                           | D_Fastening_OK  | 7         | 25                                                                                                                           | Fastening OK    |
| IN_COM                                                                                                                                             |                 | 8         | 22                                                                                                                           | 0V DC           |
| OUT_COM                                                                                                                                            |                 | 9         | 21                                                                                                                           | 24V DC          |

**NOTE:** Select HDC/SDC tool interface in DPC Touch operating settings. Select PLC (except Start and Reverse) interface on HDC/SDC controller.




## 9.7 Connection of Atlas PF4000

| DPC <b>Touch</b>                                                                  |                            |         |          | DOGA HDC/SDC series                                                                 |          |     |                |
|-----------------------------------------------------------------------------------|----------------------------|---------|----------|-------------------------------------------------------------------------------------|----------|-----|----------------|
|  |                            |         |          |  |          |     |                |
| I/O adaptor (DB44M to DB9F + DB25F)                                               |                            |         |          | I/O connectors (12 + 10 contacts)                                                   |          |     |                |
|                                                                                   |                            | ONE OF  |          |                                                                                     |          |     |                |
| I/O number                                                                        | Signals assignment example | DB9 pin | DB25 pin | Signals assignment example                                                          | Contacts |     | I/O            |
| Input 8                                                                           | D_Fastening_OK             | 5       | 13       | Tightening OK                                                                       | 1        | NO  | OUTPUT RELAYS  |
|                                                                                   |                            |         |          |                                                                                     | 2        | C   |                |
|                                                                                   |                            |         |          |                                                                                     | 3        | NC  |                |
| Input 9                                                                           | Job select 1               | 6       | 14       | Select Job 0                                                                        | 4        | NO  |                |
|                                                                                   |                            |         |          |                                                                                     | 5        | C   |                |
|                                                                                   |                            |         |          |                                                                                     | 6        | NC  |                |
| Input 10                                                                          | Job select 2               | 7       | 15       | Select Job 1                                                                        | 7        | NO  |                |
|                                                                                   |                            |         |          |                                                                                     | 8        | C   |                |
|                                                                                   |                            |         |          |                                                                                     | 9        | NC  |                |
| Input 11                                                                          | Job select 3               | -       | 16       | Select Job 2                                                                        | 10       | NO  |                |
|                                                                                   |                            |         |          |                                                                                     | 11       | C   |                |
|                                                                                   |                            |         |          |                                                                                     | 12       | NC  |                |
| Output 1(5)                                                                       | Torque Select 1            | 1       | (7)      | Pset select 0                                                                       | 13       | +   | DIGITAL INPUTS |
|                                                                                   |                            |         |          |                                                                                     | 14       | -   |                |
| Output 2(6)                                                                       | Torque Select 2            | 2       | (8)      | Pset select 1                                                                       | 15       | +   |                |
|                                                                                   |                            |         |          |                                                                                     | 16       | -   |                |
| Output 3(7)                                                                       | Torque Select 3            | 3       | (9)      | Pset select 2                                                                       | 17       | +   |                |
|                                                                                   |                            |         |          |                                                                                     | 18       | -   |                |
| Output 4                                                                          | Tool Enable                | 4       | 25       | Tool Enable                                                                         | 19       | +   |                |
|                                                                                   |                            |         |          |                                                                                     | 20       | -   |                |
| OUT_COM (24V)                                                                     |                            | 9       | 23,24    | Power supply                                                                        | 21       | 24V |                |
| IN_COM (GND)                                                                      |                            | 8       | 21,22    | Ground                                                                              | 22       | GND |                |

**NOTE:** Select DC Tool interface in DPC Touch operating settings

- Either DB25 or DB9 connectors can be used depending on desired number of I/O's
- If DB9 connector is used, then max 3 jobs can be selected on DPC Touch in binary logic by using 2 contacts.
- In order to use independent power supply to DPC Touch, do not connect 24V contact.

## 9.8 Connection of Stanley Alpha and Kappa tools




| DPC <b>Touch</b>                                                                   |                 |           | Stanley Alpha/Kappa                                                                 |                        |
|------------------------------------------------------------------------------------|-----------------|-----------|-------------------------------------------------------------------------------------|------------------------|
|   |                 |           |  |                        |
| <b>I/O adaptor</b><br>(DB44 male to DB9 female and DB25 female)                    |                 |           | <b>I/O port</b>                                                                     |                        |
|  |                 |           |  |                        |
| Input/Output                                                                       | Assigned signal | DB9 pin № | Stanley pin №                                                                       | Signal                 |
| Output 1                                                                           | Torque Select 1 | 1         | P                                                                                   | Select Job (bit)       |
| Output 2                                                                           | Torque Select 2 | 2         | R                                                                                   | Select Job (bit)       |
| Output 3                                                                           | Torque Select 3 | 3         | S                                                                                   | Select Job (bit)       |
| Output 4                                                                           | Tool Disable    | 4         | M                                                                                   | Disable Tool           |
| Input 8                                                                            | D_Motor_Run     | 5         | C                                                                                   | Tool Running / Trigger |
| Input 9                                                                            | Tool Alarm      | 6         | K                                                                                   | Cycle NOK              |
| Input 10                                                                           | D_Fastening_OK  | 7         | J                                                                                   | Cycle OK               |
| IN_COM                                                                             |                 | 8         | V                                                                                   | 0V DC                  |
| OUT_COM                                                                            |                 | 9         | B                                                                                   | 24V DC                 |

**NOTE:** Select DC tool interface in DPC Touch operating settings.

In order to use 24V supply from Stanley controller, short connect pins A and B. In this case DPC Touch will be powered by Stanley controller. Don't connect DPC Touch to external power in this case.

To decouple DPC Touch power supply and I/O external power supply, cut the bridges (15)-(35) and (30)-(31) in the DB44 connector of the I/O adaptor in order to disconnect 24V power supply.

## 9.9 Connection of Kolver EDU Series tools

| DPC <b>Touch</b>                                                                   |                 |           | KOLVER EDU Series                                                                   |                |
|------------------------------------------------------------------------------------|-----------------|-----------|-------------------------------------------------------------------------------------|----------------|
|   |                 |           |   |                |
| <b>I/O adaptor</b><br>(DB44 male to DB9 female and DB25 female)                    |                 |           | <b>CN1 port</b><br>(10 contacts)                                                    |                |
|  |                 |           |  |                |
| Input/Output                                                                       | Assigned signal | DB9 pin № | CN1 contact №                                                                       | Signal         |
| Output 1                                                                           |                 | 1         |                                                                                     |                |
| Output 2                                                                           |                 | 2         |                                                                                     |                |
| Output 3                                                                           |                 | 3         |                                                                                     |                |
| Output 4                                                                           | Tool Disable    | 4         | 4                                                                                   | Stop 5V in     |
| Input 8                                                                            | D_Fastening_OK  | 5         | 6                                                                                   | Torque 24V out |
| Input 9                                                                            | D_Motor_Run     | 6         | 7                                                                                   | Lever 24V out  |
| Input 10                                                                           | Tool Alarm      | 7         | 8                                                                                   | Error 24V out  |
| IN_COM                                                                             |                 | 8         | 9                                                                                   | Com 0V DC      |
| OUT_COM                                                                            |                 | 9         | 1                                                                                   | Com 0V DC      |

**NOTE:** Select DC tool interface in DPC Touch operating settings.






**ATTENTION!** Cut the bridges (15)-(35) and (30)-(31) in the DB44 connector of the I/O adaptor in order to disconnect 24V power supply before making the interface.

## 9.10 Two tools wiring example



Tool A is connected through DB9 connector


Tool B is connected through DB25 connector



Inputs and outputs shown in **bold text** are mandatory, *others* are optional.

Logical outputs (Lock A and Lock B) are used inside a job. Corresponding output should be enabled (Continuous On signal) in a Logical Out step to lock corresponding tool during fastening step that follows.

## 9.11 Automation equipment wiring example



## 9.12 I/O port adaptor (DB44 → DB25 + DB9) wiring scheme

|         | DPC Touch | DB44 (male) |   | DB25 (female) | DB9 (female) | Example of assigned signals |
|---------|-----------|-------------|---|---------------|--------------|-----------------------------|
| INPUTS  | Input 1   | 1           | ← | 1             |              | Job select 1                |
|         | Input 2   | 2           | ← | 2             |              | Job select 2                |
|         | Input 3   | 3           | ← | 3             |              | Job select 3                |
|         | Input 4   | 4           | ← | 4             |              | Job select 4                |
|         | Input 5   | 5           | ← | 5             |              | Reset                       |
|         | Input 6   | 6           | ← | 6             |              | Reset Step                  |
|         | Input 7   | 7           | ← | 12            |              | Reset Job                   |
|         | Input 8   | 8           | ← | 13            | 5            | D_Motor_Run                 |
|         | Input 9   | 9           | ← | 14            | 6            | Tool Alarm                  |
|         | Input 10  | 10          | ← | 15            | 7            | D_Fastening_OK              |
|         | Input 11  | 11          | ← | 16            |              | Logical In                  |
|         | Input 12  | 12          | ← | 17            |              | Logical In                  |
|         |           | 13          |   |               |              |                             |
|         | IN_COM    | 14          |   | 21, 22        | 8            | Out Com (0V)                |
|         |           | 15          |   |               |              |                             |
| OUTPUTS | Output 1  | 16          | → |               | 1            | Torque Select 1             |
|         | Output 2  | 17          | → |               | 2            | Torque Select 2             |
|         | Output 3  | 18          | → |               | 3            | Torque Select 3             |
|         | Output 4  | 19          | → | 25            | 4            | Tool Disable                |
|         | Output 5  | 20          | → | 7             |              | Tool Enable                 |
|         | Output 6  | 21          | → | 8             |              | D_Run                       |
|         | Output 7  | 22          | → | 9             |              | D_Torque                    |
|         | Output 8  | 23          | → | 10            |              | Alarm                       |
|         | Output 9  | 24          | → | 11            |              | Job OK                      |
|         | Output 10 | 25          | → | 18            |              | Logical Out                 |
|         | Output 11 | 26          | → | 19            |              | Logical Out                 |
|         | Output 12 | 27          | → | 20            |              | Logical Out                 |
|         |           | 28          |   |               |              |                             |
|         | OUT_COM   | 29          |   | 23, 24        | 9            | In Com (24V)                |
|         |           | 30          |   |               |              |                             |
|         | +24V      | 31          | → |               |              |                             |
|         |           | 32          | → |               |              |                             |
|         |           | 33          | → |               |              |                             |
|         |           | 34          |   |               |              |                             |
|         | 0V        | 35          | → |               |              |                             |
|         |           | 36          | → |               |              |                             |
|         |           | 37          | → |               |              |                             |
|         |           | 38          |   |               |              |                             |
|         |           | 39          |   |               |              |                             |
|         |           | 40          |   |               |              |                             |
|         |           | 41          |   |               |              |                             |
|         |           | 42          |   |               |              |                             |
|         |           | 43          |   |               |              |                             |
|         |           | 44          |   |               |              |                             |



### ATTENTION!



By default, the controller provides 24V output on the pins 31-33 and 35-37. This power supply can only be used to power I/O signals (max 100mA per output, max 500mA for all outputs). The controller can also be powered by external power supply through I/O port.

Bridges (15)-(35) and (30)-(31) are made inside DB44 male connector. Cut them, if signals are to be powered by external power supply

## 10. Troubleshooting

| Problem                                           | Solution                                                                                                                                                                                                                                                                                                                                                                               |
|---------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Controller is not booted (black booting screen)   | Check the boot log on the screen. Last booting step indicates the problem.<br>Example: "SD card Init" – SD card is not found. Check if SD card is inserted and not damaged.                                                                                                                                                                                                            |
| Operating screen is not displayed after booting   | SD card content can't be found. Check if "system" and "user" folders are placed in the root directory of the SD card and not placed in other folders. Check if names of folders are correct. Rewrite the "system" folder content if necessary.                                                                                                                                         |
| Controller is not responding after calibration    | Calibration is not performed correctly.<br>Turn off the controller and delete the following file from the SD card:<br><b>SD:\system\setting\Setting_posi.dat</b>                                                                                                                                                                                                                       |
| Password is lost or forgotten                     | Turn off the controller and delete the following file from the SD card:<br><b>SD:\system\setting\Setting_posi.dat</b>                                                                                                                                                                                                                                                                  |
| Controller is unresponsive                        | Turn off and on the controller.                                                                                                                                                                                                                                                                                                                                                        |
| Input signal is not received                      | Input signals should be between 20 and 30V in order to be detected by controller. Check if signal is detected in Other settings, real time monitoring                                                                                                                                                                                                                                  |
| Output signal is not sent                         | Max current capacity of outputs is 100 mA per output and total of 500mA for all outputs. To check wiring, force output signal in Other settings, real time monitoring. Outputs are optically isolated.                                                                                                                                                                                 |
| Image message is overlapped with operating screen | Press on the screen where Image button is situated (top middle) in order to initialize the screen. Use recommended pictures format 16 bit bitmap. To convert images into 16 bit format use image converter utility.                                                                                                                                                                    |
| Image message is not displayed on the screen      | Check image size and format. Images have to be in .bmp format of the following size: 800x480 px. Recommended bit depth is 16 bit. To convert images into 16 bit format use image converter utility.                                                                                                                                                                                    |
| Job is locked in a loop with no end               | Turn off and on the controller. If the job is assigned as default, delete the job from the SD card. Make sure that a job contains at least one Fastening or one Logical input step. Otherwise the job will be stuck in automatic loop.                                                                                                                                                 |
| Error: "Fastening time is too short/long"         | Check fastening time control limits in operating settings (screen 3 of 4). Check saved min and max fastening time in corresponding fastening step. Reprogram or modify manually if needed. To disable tightening time control set min and max fastening time to 0 in fastening step programming.<br>NOTE: control limits in operating settings are only applied to newly created jobs. |
| Error: "Trigger released before torque up"        | Check min threshold for trigger release control in operating settings (screen 3 of 4). If start trigger is released after the min threshold, the error is displayed. To disable trigger release control, set the threshold to 0 or to 9999.                                                                                                                                            |



8, avenue Gutenberg - CS 50510  
78317 Maurepas Cedex - France  
Tél. : +33 (0)1 30 66 41 48 • Fax : +33 (0)1 30 66 41 49  
[export@doga.fr](mailto:export@doga.fr)



Nous travaillons constamment à l'amélioration de nos produits. De ce fait, les dimensions et indications portées dans cette brochure peuvent parfois ne pas correspondre aux dernières exécutions. De convention expresse, nos ventes sont faites sous bénéfice de réserve de propriété (les dispositions de la loi du 12/5/80 trouvent donc toute leur application).